







H	180		200	
L	X	Y	X	Y
32.9	12.6	151.5	12.6	171.5
41.3	21.0	151.5	21.0	171.5
49.7	29.4	151.5	29.4	171.5
58.1	37.8	151.5	37.8	171.5
66.5	46.2	151.5	46.2	171.5



Ze względów bezpieczeństwa kotki rozporowe nie są dostarczane w komplecie. Dobierz odpowiednie kotki do swojej ściany.

OPCJA

Kod 5090.1111 Kod 5090.1110 Kod 5090.1119
 Kod 5094.425 Kod 5090.1111 Kod 5094.427

Standard

Złącza do instalacji znajdziesz w katalogu Jaga www.jaga.com.pl

